




# Operating Instructions



STP01-DRU01

Pneumatic Hydraulic Stackers with Manual  
Drum Rotation

Bespoke Handling Equipment Ltd.  
Leedstown  
Hayle  
Penzance  
TR27 6DS

E-mail: [sales@sts-trolleys.co.uk](mailto:sales@sts-trolleys.co.uk)

Tel: +44 (0)1736 851050

Fax: +44 (0)1736 851023

<b>Section I – Correct Use and Application</b> .....	<b>2</b>
<b>Section II – Unit Description</b> .....	<b>5</b>
<b>Section III – Unit Operation</b> .....	<b>6</b>
Set Up.....	6
Moving the Unit .....	6
Operation of the Control Lever Up and Down .....	7
Clamping the Drum.....	7
Operations of Tipping the Drum .....	8
Using the 25 Litre Adaptor (Optional Extra) .....	8
<b>Section IV – Unit Maintenance</b> .....	<b>9</b>
Maintenance Checklist.....	9
Consumables.....	9
Trouble Shooting .....	10
<b>Section V - Technical Specification</b> .....	<b>11</b>
General Arrangement .....	11
<b>Section VI - Decommissioning the Unit</b> .....	<b>12</b>
Final De-commissioning and Disposal .....	12
Safety Tests to be performed at Intervals and after Unusual Incidents.....	12

# Section I – Correct Use and Application

## General

The unit described in the present operating instructions is designed for lifting, lowering and transporting load units. It must be used, operated and serviced in accordance with the present instructions. Any other type of use is beyond the scope of application and can result in damage to personnel, the unit or property.

## Correct Application

### NOTE:

The maximum load must not be exceeded.  
The load must be lifted by the attachment provided by the manufacturer.  
Correct applications of this unit are as follows:

- Lifting and lowering of loads
- Transporting lowered loads
- Do not travel with a raised load (>500mm)
- Do not carry or lift passengers
- Do not negotiate on inclines

## Approved Application Conditions

- Operation in industrial and commercial environments
- Permissible temperature range 5°C to 40°C
- Operation only on secure, level surfaces with sufficient capacity
- Operation only on routes that are visible and approved by the proprietor

## Proprietor Responsibilities

For the purposes of the present operating instructions the "proprietor" is defined as any natural or legal person who either uses the unit himself, or on whose behalf it is used. In special cases (e.g. leasing or renting) the proprietor is considered the person who, in accordance with existing contractual agreements between the owner and user of the unit, is charged with operational duties. The proprietor must ensure that the unit is used only for the purpose for which it is intended and that there is no danger to life and limb of the user and third parties. Furthermore, accident prevention regulations, safety regulations and operating, servicing and repair guidelines must be followed. The proprietor must ensure that all users have read and understood these operating instructions.

### NOTE:

Failure to comply with the operating instructions shall invalidate the warranty. The same applies if improper work is carried out on the unit by the customer or third parties without the permission of the manufacturer.

## Adding Attachments and/or Accessories

The mounting or installation of additional equipment which affects or enhances the performance of the unit requires written permission of the manufacturer. Local authority approval may also need to be obtained. Local authority approval does not however constitute the manufacturer's approval.

## Safety Regulations for the Operation of the Unit

### Driver authorisation

The unit may only be used by suitably trained personnel, who have demonstrated to the proprietor, or his representative that they can drive and handle the loads and have been authorised to operate the unit by the proprietor or his representative.

### Driver's rights, obligations and responsibilities

The driver must be informed of his duties and responsibilities and be instructed in the operation of the unit and shall be familiar with the operating instructions. The driver shall be afforded all due rights. Safety shoes must be worn for pedestrian units.

### Unauthorised use of unit

The driver is responsible for the unit during the time it is in use. The driver must prevent unauthorised persons from driving or operating the unit. Do not carry passengers or lift other people.

### Damage and faults

The supervisor must be immediately informed of any damage or faults to the unit or attachment. Units which are unsafe for operation (e.g. wheel or brake problems) must not be used until they have been rectified.

### Repairs

The driver must not carry out any repairs or alterations to the unit without the necessary training and authorisation to do so. The driver must never disable or adjust safety mechanisms or switches.

### Hazardous area

### WARNING! Risk of accidents / injury in the hazardous area of the unit.

The hazardous area is defined as the area in which a person is at risk due to unit movement, lifting operations, the handler (e.g. forks or attachments) or the load itself. This also includes areas which can be reached by falling loads or lowering operating equipment.

- Instruct unauthorised people to leave the hazardous area
- Give a warning signal with plenty of time for people to leave
- If unauthorised personnel are still within the hazardous area stop the unit immediately

### Safety devices and warning labels

Safety devices, warning signs and warning instructions in the present operating instructions must be strictly observed.

### Travel routes and work areas

Only use lanes and routes specifically designated for unit traffic. Unauthorised third parties must stay away from work areas. Loads must only be stored in places specifically designated for this purpose. The unit must only be operated in work areas with sufficient lighting to avoid danger to personnel and materials. Additional equipment is necessary to operate the unit in areas of insufficient lighting.

### DANGER!

Do not exceed the permissible surface and spot load limits on the travel routes. At blind spots get a second person to assist.

### Travel conduct

The driver must adapt the travel speed to local conditions. The unit must be driven at slow speed when negotiating bends or narrow passageways, when passing through swing doors and at blind spots. Abrupt stopping (except in emergencies), rapid U turns and overtaking at dangerous or blind spots are not permitted. Do not lean out or reach beyond the working and operating area.

### Travel visibility

The driver must look in the direction of travel and must always have a clear view of the route ahead. Loads that affect visibility must have a second person walk alongside the unit as a lookout to observe the travel route while maintaining eye contact with the driver. Proceed only at walking pace and with particular care.

### Negotiating slopes and inclines

Negotiating slopes or inclines is only permitted if they are specifically designed as travel routes, are clean and have a non-slip surface and providing they can be safely travelled along in accordance with the unit's technical specifications. The unit must not be turned, operated at an angle or parked on inclines or slopes. Inclines must only be negotiated at slow speed, with the driver ready to brake at any moment.

#### **Type of loads to be carried**

The operator must make sure that the load is in a satisfactory condition. Loads must always be positioned safely and carefully. Use suitable precautions to prevent parts of the load from tipping or falling down. Prevent liquid loads from sloshing out.

### **Safety Regulations for Operation**

#### **Travel routes and work areas**

Only use lanes and routes specifically designated for unit traffic. Unauthorised third parties must stay away from work areas. Loads must only be stored in places specially designated for this purpose. The unit must only be operated in work areas with sufficient lighting to avoid danger to personnel and materials. Additional equipment is necessary to operate the unit in areas of insufficient lighting.

#### **DANGER!**

Do not exceed the permissible surface and spot load limits on the travel routes. At blind spots get a second person to assist. The driver must ensure that the load dock/ramp cannot move or come loose during loading/unloading.

#### **Travel conduct**

The driver must adapt the travel speed to local conditions. The unit must be driven at slow speed when negotiating bends or narrow passageways, when passing through swing doors and at blind spots. The driver must always observe an adequate braking distance between the unit and the vehicle in front and must be in control of the unit at all times. Abrupt stopping (except in emergencies), rapid U-turns and overtaking at dangerous or blind spots are not permitted. Do not lean out or reach beyond the working and operating area.

#### **Travel visibility**

The driver must look in the direction of travel and must always have a clear view of the route ahead. Loads that affect visibility must be positioned at the rear of the unit. If this is not possible, a second person must walk alongside the unit as a lookout to observe the travel route while maintaining eye contact with the driver. Proceed only at walking pace and with particular care. Stop the unit as soon as you lose eye contact.

#### **Negotiating slopes and inclines**

Negotiating slopes or inclines is only permitted if they are specifically designed as travel routes, are clean and have a non-slip surface and providing they can be safely travelled along in accordance with the unit's technical specifications. The unit must always be driven with the load facing uphill. The unit must not be turned, operated at an angle or parked on inclines or slopes. Inclines must only be negotiated at slow speed, with the driver ready to brake at any moment.

#### **Negotiating lifts and docks**

Lifts may only be entered if they have sufficient capacity, are suitable for driving on and authorised for unit traffic by the owner. The driver must satisfy himself of the above before entering these areas. The unit must enter lifts with the load in front and must take up a position which does not allow it to come into contact with the walls of the lift shaft. People travelling in the lift with the unit must only enter the lift after the unit has come to a halt and must exit the lift before the unit. The driver must ensure that the loading ramp/bridge cannot move or come loosed during loading/unloading.

#### **Types of loads to be carried**

The operator must make sure that the load is in a satisfactory condition. Loads must always be positioned safely and carefully. Only lift loads as specified for the unit.

### **Unit Operation**

#### **WARNING!**

#### **Unsecured and incorrectly positioned loads can cause accidents**

Before lifting a load unit the driver must make sure that it has been correctly positioned and does not exceed the unit's capacity.

- Instruct other people to move out of hazardous area of the unit. Stop working with the unit if people do not leave the hazardous area
- Only carry loads that have been correctly secured and positioned. Used suitable precautions to prevent parts of the load from tipping or falling down
- Damaged loads must not be transported
- Never exceed the maximum load capacity of the unit
- Never stand underneath a raised load handler
- Do not stand on the load handler
- Do not lift other people on the load handler

#### **WARNING!**

#### **Risk of accidents and damage to components**

All modifications to the unit, in particular safety mechanisms, are prohibited. The operating speeds of the unit must not be increased under any circumstances.

#### **NOTE:**

Only original spare parts have been certified by the manufacturer. To ensure safe and reliable operation of the unit, use only the manufacturer's spare parts.

### **Maintenance Safety Regulations**

#### **Maintenance Personnel**

The unit should only be serviced and repaired by the manufacturer's specialist customer service personnel who have been trained to do this.

#### **Lifting and jacking up**

#### **WARNING!**

#### **Lifting and jacking up the unit safely**

In order to raise the unit, the lifting gear must only be secured to the points specially provided for this purpose. You may only work under a raised load handler if they have been secured with a sufficiently strong chain. In order to raise and jack up the unit safely, proceed as follows:

- Jack up the unit only on a level surface and prevent it from moving accidentally
- Always use a jack with sufficient capacity. When jacking up the unit, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks, etc.)
- In order to raise the unit, the lifting gear must only be secured to the points specially provided for this purpose (see "Transport and Commissioning")
- When jacking up the unit, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks)

#### **Consumables and Used parts**

#### **CAUTION!**

#### **Consumables and Used parts are an environmental hazard**

Used parts, oils and fuels must be disposed of in accordance with the relevant environmental protection regulations. To change the oil contact the manufacturer's customer service department, who have been specially trained for this task.

- Note the safety regulations when handling these materials

#### **Hydraulic hoses**

**WARNING!****Brittle hydraulic hose lines cause accidents**

The hoses must be replaced every six years. The manufacturer's customer service department is specially trained to carry out these operations.

- Comply with the safety regulations for hydraulic hose lines in accordance with BGR 237

**WARNING!****Hydraulic line leaks cause accidents**

Hydraulic oil can escape from leaky and faulty hydraulic lines.

- Report any defects immediately to your supervisor
- Tag out and decommission a faulty unit
- Only return the unit to service when you have identified and rectified the fault
- Spilled fluids must be removed immediately with an appropriate bonding agent. The bonding agent / consumable mixture must be disposed of in accordance with regulations

**WARNING!****Hairline cracks in the hydraulic lines can cause injury and infection**

Pressurised hydraulic oil can penetrate the skin through fine holes or hairline cracks in hydraulic lines, causing severe injury.

- Call for a doctor immediately if you are injured
- Do not touch pressurised hydraulic lines
- Report any defects immediately to your supervisor
- Tag out and decommission a faulty unit
- Only return the unit to service when you have identified and rectified the fault
- Spilled fluids must be removed immediately with an appropriate bonding agent. The bonding agent / consumable mixture must be disposed of in accordance with regulations

**Lift Chains****WARNING!****Incorrectly cleaned chains can cause accidents**

Lift chains are safety-critical parts. They must not contain any serious contamination. Lift chains and pivot pins must always be clean.

- Lift chains should only be cleaned with paraffin derivatives e.g. petroleum or diesel fuels
- Never clean chains with steam jet high pressure cleaners, cold or chemical cleaning agents
- Immediately after cleaning, dry the lift chain with compressed air and apply a chain spray

**Servicing and Inspection**

Thorough and expert servicing is one of the most important requirements for the safe operation of the unit. Failure to perform regular servicing can lead to unit failure and poses a potential hazard to personnel and equipment.

**WARNING!**

The application conditions of a unit have considerable impact on the wear of the service components.

**Lifting the Unit****WARNING!****Improper lifting by crane can result in serious accidents**

The use of unsuitable lifting gear can cause the unit to crash when being lifted by crane. Prevent the unit from striking other objects when it is being raised, and avoid any involuntary movements. If necessary secure the unit with guide ropes. The strap point on the mast is for loading the unit with lifting gear.

- The unit should only be handled by people who are trained in using lifting slings and tools
- Do not walk into or stand in a hazardous area
- Always use lifting gear with sufficient capacity
- Always attach the slings to the prescribed strap points and prevent them from slipping

**WARNING!****Accidental movement during transport**

Improper fastening of the truck and mast during transport can result in serious accidents.

- Loading must be carried out by special trained staff in accordance with recommendations contained in Guidelines BS EN 12640:2001. In each case correct measurements must be made and appropriate safety measures adopted
- The unit must be securely fastened when transported on a lorry or trailer
- The lorry/trailer must have fastening rings
- Use wedges to prevent the unit from moving
- Use only tension belts or tie-down straps or with sufficient strength

The strap point on the mast is for loading the unit with crane lifting gear.

**Lifting the Unit****Requirements**

- Park the unit securely

**Tools and Material Required**

- Lifting gear

**Procedure**

- Secure Lifting slings to the strap point

The unit can now be lifted.


**Securing the truck for transport****Tools and Material Required**

- Tension belts/tie down straps

**Procedure**

- Move the unit onto the transporting truck
- Park the unit securely
- Strap the belts around the unit and tension them sufficiently, utilising the strap points on the mast

The unit can now be transported.



## Section II – Unit Description

The STP01-DRU01 is a four-wheeled pedestrian stacker with a universal drum rotator band. It is designed for use on level surfaces to lift, rotate and transport a variety of drums. The unit is Pneumatic Hydraulic powered with manual rotation.


The drum would be stood vertical; the unit can then approach the drum and straddle either side. The band is pushed flush to the drum and then fastened around the drum. Once the rim clamp is adjusted and fastened to the top lip of the drum, it can then be lifted, transported and rotated.

The STP01-DRU01 is designed to pick up and rotate drums ranging from 50–230 litres, steel or plastic drums with a diameter of between 400-600mm.

The unit incorporates enclosed, smooth geometry with rounded edges to ensure safe handling of the unit. The unit is fitted with a fully enclosed pump/ram unit which is operated by two-handed controls to keep operator's limbs away from dangerous machinery movement.

**The Safe Working Load (SWL) of this unit is 350kg**

## Section III – Unit Operation



### IMPORTANT

Before using the STP01-DRU01 Air operated drum lifter operators must read and understand this instruction manual. Failure to observe the instructions in this manual will invalidate the warranty.

The Maximum weight of drum that the unit should be used to pick up is **350kg**.

### Set Up

1. The STP01-DRU01 requires a dry clean air supply, which should be connected to the unit via a flexible air hose fitted with a quick release coupling. The unit will operate with a maximum pressure of 9 BAR.
2. The STP01-DRU01 is now ready to use.

### Moving the Unit

#### Requirements

- Load correctly lifted
- Load at correct height for transport.
- Good ground conditions

#### Procedure

- Disengage the Rear Parking Brakes
- The unit can then be manoeuvred to the desired location
- Steering is controlled from the rear of the stacker
- Travel at a constant speed
- Adapt your travel speed to the conditions of the route and the load you are transporting
- When finished manoeuvring the Rear Parking Brakes should be engaged

## Operation of the Control Lever Up and Down

1. To lift the drum rotator the operator simply pulls the lift/lower lever at the rear of the unit. As the lever is pulled the carriage will go up and when the lever is let go or returned to the middle position the carriage will stop.
2. To lower the drum rotator, simply push the lever forward and the carriage will go down.
3. The control lever operates on a dead-man's principle for safety.
4. There is a red Emergency Stop button on top of the control panel. To stop all movement of the Lift, lower or rotate press the button down. To re-set the button, turn clock wise.
5. The unit is safe even if the airline is disconnected during the operation of the unit. The load will simply stop where it is.
6. The unit requires air to be connected to operate any functions but the air supply may be disconnected to manoeuvre the unit.

## Clamping the Drum


### Setting the DRU01 for your drum type

1. The drum should be sitting on the floor vertically.
2. Open up the arms on the rotator to the full width.
3. Push the stacker forward so that the rotator band goes around the drum.
4. There are 2 pivot points, one on each arm. One is the gearbox pivot and the other is a free pivot. These should be positioned at the middle of the drum. (this means push or pull the stacker until the pivots are in the middle of the drum)
5. Push the two arms in so that the two pivot band sections touch the drum.
6. Adjust the height of the clamping band by raising or lowering the stacker until the clamping band is in the middle of the drum (this means top to bottom middle)
7. Adjust the back section of the clamping band to suit the diameter of the drum by removing the two locking 'R' clips from the rear of the clamping band then adjust the band to the correct diameter of the drum then refit the two 'R' clips. (The rear section of the band should be complete from the two pivot points.)
8. Fold the two front sections of the drum clamp band around the front so that they touch the drum.



9. Hook the 'D' ring that is on the end of the blue strap onto the securing pin, which is on the last band section on the left hand arm.
10. Pull on the tail end of the blue strap to take out the slack.
11. Use the ratchet to tension the clamping band. (This should be tightened until the drum starts to show signs of deflection).

12. The rim clamp must be connected to the top lip of the drum. The height can be set by removing the 'R' clip, which is close to the right hand pivot, and removing the pin. The rim clamp arm can now be set to the correct height to suit the drum size. Ensure that the top of the drum rim clamp arm is positioned under the top rim of the drum. Whilst this is being held in place the top swivelling clamp can be positioned over the rim of the drum. You can now clamp the two together by screwing down the butterfly nut. You should check that the top drum lip is securely clamped between the two sections of the drum rim clamp.




13. Replace the clamping arm adjustment pin through the body of the rotator bracket.
14. Replace the locking 'R' pin.
15. **IMPORTANT** - Check steps 1-14 have been completed correctly before you lift the drum off the floor. If you are in any doubt then contact the STS Technical support line. +44 1736 851 050

## Operations of Tipping the Drum

1. To tip the drum the operator simply rotates the handle on the side of the DRU01 to tip the drum forwards and backwards. If the drum is tipped and the handle is released the drum will stay in its current position.

## Using the 25 Litre Adaptor (Optional Extra)

The unit can also be supplied with an adaptor that is fitted to the gearbox side of the clamping band with 2 locking pins. This is used to reduce the clamping width of the clamping band. With this adaptor fitted the clamping system using the ratchet should be used. The adaptor should only be used to pick up small drums that do not fit in the normal head arrangement.



**ISOLATE THE AIR SUPPLY WHEN NOT IN USE**

## Section IV – Unit Maintenance

### Maintenance Checklist

The follow servicing checklist indicates the operations to be performed and the respective intervals to be observed. Maintenance intervals are defined as:

- W = Every 50 service hours, at least weekly
- A = Every 1000 service hours, at least annually
- = Standard maintenance interval

*During the run-in period – after approx. 100 service hours – the owner must check the wheel nuts/bolts and re-tighten if necessary.*

<b>Brakes</b>		<b>W</b>	<b>A</b>
1	Test brakes.	●	●

<b>Travel</b>		<b>W</b>	<b>A</b>
1	Check wheels for wear and damage	●	●

<b>Hydraulic Operations</b>		<b>W</b>	<b>A</b>
1	Check carriage and head (load handler) for wear and damage.	●	●
2	Test hydraulic system.	●	●
3	Check hydraulic oil and top up if necessary.	●	●
4	Check the load chain for wear and damage, clean if necessary.	●	●
5	Visually inspect the mast bearings and check contact surface wear level		●
6	Check lateral clearance of mast connections and carriage		●
7	Check the load chain and tension if necessary		●
8	Check that hydraulic ports, hose and pipe lines are secure, check for leaks and damage.		●
9	Check cylinders and piston rods for damage and leaks, and make sure they are secure.		●
10	Test "hydraulic" controls and make sure the labels are present, legible and complete.		●
11	Replace hydraulic oil.		●
12	Check and replace if required pneumatic filter elements		

<b>Chassis and Superstructure</b>		<b>W</b>	<b>A</b>
1	Check doors and/or covers	●	●
2	Check labels are legible and complete	●	●
3	Check mast guard for damage	●	●
4	Check chassis and screw connections for damage		●

<b>Agreed Performance Level</b>		<b>W</b>	<b>A</b>
1	Carry out a test run with rated load, if necessary with customer specified load		●

### Consumables

Bespoke Handling Equipment stackers are factory-equipped with Shell Tellus 32 oil for the hydraulic system. It is recommended to use as stated or an equivalent when replacing hydraulic oil.

The blue ratchet strap of the Universal Drum Band should be replaced if any stranding of webbing is visible. These are available from Bespoke Handling Equipment. The strap should be changed twice a year even if it shows no signs of wear.

## Trouble Shooting

When trying to locate a fault, proceed in the order shown in the table.

### NOTE:

Troubleshooting must only be performed by a suitably competent individual as decided by the company the equipment is intended for use with.

If, after carrying out the follow remedial action, the unit cannot be restored to operation, contact the manufacturer's technical helpline. In order for customer services to react quickly and specifically to the fault, the following information is essential:

- Unit serial number
- Description of error
- Unit product name
- Current location / Company

### Load cannot be lifted

Possible Cause	Action
The load exceeds the SWL	Reduce mass of load
Hydraulic oil level too low	Check Hydraulic oil level
Air Pressure too low	Check air supply
Emergency Stop engaged	Reset Emergency Stop button

### Load cannot be lowered



Possible Cause	Action
Emergency Stop engaged	Reset Emergency Stop button
Air pressure too low	Check air supply

### Unit cannot be moved

Possible Cause	Action
Rear Parking Brakes are engaged	Release the Rear Parking Brakes

## Section V - Technical Specification


### General Arrangement



15° OF TIP

30° OF TIP

60° OF TIP



NOTE: STANDARD 205L STEEL DRUM USED FOR 2D DRAWING. TIPPING HEIGHTS WILL VARY FOR OTHER SIZED DRUMS

**SWL. 350kg**

**Net Mass. 340kg**

**Max Noise Level. 79dBA**

## Section VI - Decommissioning the Unit

If the unit is to be out of service for more than a month, e.g. for commercial reasons, it must be stored in a frost-free and dry room. All necessary measures must be taken before, during and after decommissioning as described hereafter.

### Prior to decommissioning

- Thoroughly clean the unit.
- Test the brakes
- Check the hydraulic oil and replenish if necessary.
- Apply a thin layer of oil or grease to any non-painted mechanical components.

### Final De-commissioning and Disposal

Final de-commissioning or disposal of the unit must be performed in accordance with the regulations of the country of use. In particular, regulations governing the disposal of batteries, fuels and electronic and electrical systems must be observed.

The truck must only be disassembled by trained personnel.

### Safety Tests to be performed at Intervals and after Unusual Incidents

Perform a safety check in accordance with national regulations.

The unit must be inspected at least annually or after any unusual event by a qualified inspector. The inspector shall assess the condition of the unit from purely a safety viewpoint, without regard to operational or economic circumstances.

For further help contact the Bespoke Handling Equipment:

**Technical Support Line: 44 (0) 1736 851050**

In the interest of all concerned it is essential that equipment of our manufacture is used only for the purposes for which it has been designed and it must be used in accordance with the instructions which are supplied.